

# PARTS LIST

## LANCASTER LAUNDRY TRAY WASTE WATER PUMPS MODELS X99A33 & X99A50

PART NO.	REQ'D.	DESCRIPTION	PART NO.	REQ'D.	DESCRIPTION
1061	1	ROTARY SEAL	3730P	1	SUCTION HOUSING PLUG
2702	1	IMPELLER FOR X99A33	3731G	1	PLATE GASKET
2714	1	O-RING	3731S	12	PLATE MOUNTING SCREW 10-24x1/2, SS
3548	1	GROMMET	3745	4	CAP SCREW, 1/4-20x5/8
3702	1	IMPELLER FOR X99A50	3751	1	DISCHARGE CASING
3707A	1	SWITCH ASSEMBLY  (INCLUDES SWITCH HOUSING WITH CORD, FLOAT, ROD, PIN, GROMMET, GASKET, PLATE AND 4 MOUNTING SCREWS)	4721A	1	CORD SET, 16/3, 8 FT. WITH PLUG, SJTOW
3730	1	SUCTION HOUSING	6-5759	1	1/2 HP MOTOR FOR X99A50
			6-5759D	1	1/3 HP MOTOR FOR X99A33

